


SYSTEM: HERU[®] CX-EXP1



In this wiring diagram we have not state any protective measures. Installation and connection of the unit according to safety and accident prevention regulations.

H. Östberg AB reserve all rights for this wiring diagram. No parts of this catalogue may be reproduced or transmitted in any form or by any mean. Infringement commits to compensation for damages and may result in criminal proceedings.

ÖSTBERG


WIRING DIAGRAM
OPTION HERU[®] CX-EXP1
EXTENDED I/O FUNCTIONS
COVER SHEET

ORDERNUMMER	RITNINGSNUMMER 999050054	
GODKÄND AV	RITAD AV	BLAD
FROS	FROS	1
DATUM	REV.	FORTS.
2017-10-31	03	2


NR.	ÄNDRING	SIGN.	DATUM
-----	---------	-------	-------

NOTE! NEEDS TO BE ACTIVATED IN THE MENU.

-
- A perspective line drawing of a rectangular metal case. The case has a handle on the front face and a latch on the top face. The drawing is a black and white line art illustration.



ON					DI
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1	2	3	4	5	6



OR

OR

OR

OR

OR

OR

OR

11

12

13

14

15

16

17

18

1

2

1

2

1

2

1

2

:5

:6

:7

:8

1 — COM

2 — NO

1 — COM

2 — NO

1 — COM

2 — NO

1 — COM

2 — NO

START DX1

START DX2

Spare

Spare

SIGNAL
POTENTIAL FREE PLUG
MAX 230V/2A