

# HERU FW Update Tool - for Windows

## EN | Instruction for the HERU FW Update Tool


1270654



### NOTICE


The update via a computer requires that you have access to Bluetooth, because you need to connect to the IQC Bluetooth module.

1. Download the *HERU FW Update Tool*, and double click on the file.
2. This pop-up window will appear:




3. Click on *Start searching* to find your unit.

# HERU FW Update Tool - for Windows




4. Click on the device with the MAC-address you want to pair with.

# HERU FW Update Tool - for Windows




The first time you connect to a new unit, use a paper clamp or similar to click the button inside the small hole in the casing of the HERU Bluetooth device. The button lights up with a blue light for 60 seconds.

5. Enter the pairing key *123456* and click *Connect*




6. The device is now paired and ready to connect.

# HERU FW Update Tool - for Windows




7. To the left in the menu, select *Connect and update*. Then click on *connect*.
8. Select the HERU IQ firmware update file (zip file for the HERU IQ app). It can be downloaded from <http://se.ostberg.com/update>

# HERU FW Update Tool - for Windows




9. Click on *Update*

# HERU FW Update Tool - for Windows



10. The *HERU IQ firmware* is now updating.

# HERU FW Update Tool - for Windows



# HERU FW Update Tool - för Windows

## SV | Instruktion för HERU FW Update Tool


1270654



### OBS!

Uppdateringen via en dator kräver att du har tillgång till Bluetooth, eftersom du behöver ansluta den till IQC Bluetooth-modulen.


1. Ladda ner *HERU FW Update Tool*, och dubbelklicka på filen.
2. Detta popup-fönster kommer att visas:



3. Klicka på *Start searching* för att hitta din enhet.




# HERU FW Update Tool - för Windows




4. Klicka på enheten med den MAC-adress du vill para ihop med.

# HERU FW Update Tool - för Windows




Första gången du ansluter till en ny enhet, använd ett gem eller liknande för att klicka på knappen inuti det lilla hålet i höljet på HERU Bluetooth-enheten. Knappen lyser med blått ljus i 60 sekunder.

5. Ange parningsnyckeln **123456** och klicka **Connect**




6. Enheten är nu parad och redo att anslutas.

# HERU FW Update Tool - för Windows




7. Till vänster i menyn, välj *Connect and update*. Klicka sedan på *connect*.
8. Välj HERU IQ-firmwareuppdateringsfilen (zip-fil för HERU IQ-appen). Den kan laddas ner från <http://se.ostberg.com/update>

# HERU FW Update Tool - för Windows



9. Klicka på *Update*

# HERU FW Update Tool - för Windows



10. *HERU IQ firmware* uppdateras nu.

# HERU FW Update Tool - för Windows

